PIG Build-A-Berm Barrier

Instructions

Step 1 — Prepare floor

The floor must be clean of debris. Any buildup of grease and oil must be removed. Failure to do so may result in premature failure of Build-A-Berm Barrier sealant.

Step 2 — Fill any cracks

To apply a Build-A-Berm Barrier over frost cracks and form separations, first fill these areas with caulking.

Step 3 — Apply caulking

Apply two continuous beads of caulking (not included) on the bottom of the Build-A-Berm Barrier, approximately 1" in from its side and ends, along its entire length.

NOTE: PLR222 and PLR511 includes caulking.



Step 4 — Build your barrier

Place Build-A-Berm Barrier and apply pressure to its entire length to seal it to the floor.

NOTE: To ensure proper sealing on uneven surfaces, you may need to apply extra sealant and more direct pressure.

Step 5 — **Customize your layout**

To add sections or attach corners to the Build-A-Berm Barrier, apply vinyl cement (not included) to the built-in vinyl cover and the end of the berm. Then mold the vinyl cover over the berm end and hold in place (approximately 30 seconds).

IMPORTANT NOTES:

- 1. If Build-A-Berm Barrier has been stored coiled, let it lie flat for two hours before installing it.
- 2. Colder climates (temperature below 70°F) may require more time for berm to relax before installing.
- 3. For better adhesion, scuff the bottom of the Build-A-Berm Barrier with sandpaper.
- 4. Let the Build-A-Berm Barrier cure (sealant and glue) for at least one hour before use.
- 5. To cut Build-A-Berm Barrier, use a utility knife and a straight edge.
- 6. To remove Build-A-Berm Barrier, scrape with a flat-blade shovel and use silicone remover to clean caulking from base.



newpig.com

North America: **1-800-468-4647** Europe: **+31 (0)76 596 92 50** UK: 0800 919 900

Outside North America: +1-814-684-0101