

## PIG® HazMat Chemical Absorbent Pillow in Dispenser Box

PIL306 Absorbs Acids; Bases; Unknowns, Absorbs up to 30 oz. per pillow, 10 pillows

When the situation calls for more than a mat, our high-capacity HazMat pillows deliver the absorbency you need for highly concentrated corrosives.

- Absorbs the widest range of acids, bases and unknown liquids, even those with high concentrations like 98% sulfuric acid and 30% sodium hydroxide
- Chemical-resistant pillow won't degrade or cause a dangerous reaction upon contact with corrosive spills
- Pillow has large surface area, high capacity and fast-wicking filler to quickly soak up liquids; great for adding absorbency during spill response
- Polypropylene skin resists chemicals and tearing; reduces dust and holds in liquid, even when saturated
- Polypropylene filler is highly absorbent for containing corrosive or reactive spills
- Pink color is easily distinguishable to assure workers use the correct pillow during a spill emergency
- Can be incinerated after use to reduce waste
- Dispenser box makes pillows easy to access, carry and store while protecting contents from dirt and moisture



### Specifications

Fluid Absorbed	Acids; Bases; Unknowns
Color	Pink
Dimensions	8" W x 8" L x 1" H
Absorbency	Up to 2.34 gal. per box
Absorbency per	Up to 30 oz. per pillow
Configuration	Pillow
Sold as	10 pillows per box
Weight	4 lbs.

# per Pallet	48
Composition	Polypropylene
UNSPSC	47131908
UV Resistant	No
Pigalog® Page Number	<u>Page 75</u>

## Metric Equivalent

Absorbency per	Up to 887.1 mL per pillow
Absorbency	Up to 8.9 L per box
Dimensions	20.3cm W x 20.3cm L x 2.5cm H
Weight	1.8 kg

## Technical Information

### Technical Documents

[PIG Hazardous Chemical Absorbents](#)

[PIG® HAZ-MAT Absorbents](#)

[29 CFR 1910.22\(a\)\(2\)](#)

### Disclaimers

#### HAZ-MAT Notice

To ensure effectiveness and your safety, we recommend that you conduct compatibility and absorption testing of your chemicals with PIG® HAZ-MAT products prior to purchase. If you have any questions or need samples to test, please call Technical Services.



**One Pork Avenue • Tipton, PA 16684-0304**

1-855-493-4647 • Fax: 1-800-621-7447 • [newpig.com](http://newpig.com) • [hothogs@newpig.com](mailto:hothogs@newpig.com)