



PIG® Acid Encapsulating & Meutralizing Pillow

PIL352 Absorbs Acids, Absorbs up to 32 oz. per pillow, 4 pillows

Absorb, encapsulate and neutralize corrosives in one easy step for safer spill cleanup. Color indication identifies the best time to handle.

- Encapsulate and neutralize the most common acid spills; great for battery charging, transport and storage areas
- Color changes as liquids are taken in, then returns to normal when neutralization is complete; helps identify the best time to handle with the least amount of risk
- Instantly absorbs up to 98% concentrations of sulfuric acid
- Gelling agents solidify acids during neutralization; prevents them from leaching out of pillow

Specifications

Fluid Absorbed	Acids
Color	Mauve
Dimensions	12" W x 12" L x 1" H
Absorbency	Up to 1 gal. per box
Absorbency per	Up to 32 oz. per pillow
Configuration	Pillow
Sold as	4 pillows per box
Weight	6 lbs.
# per Pallet	360
Composition	Skin - Polypropylene Filler - Sodium Carbonate, Alizarin
UNSPSC	47131908
UV Resistant	No
Pigalog® Page Number	Page 77

Metric Equivalent

Absorbency per	Up to 946.2 mL per pillow	

 Absorbency
 Up to 3.8 L per box

 Dimensions
 30.5cm W x 30.5cm L x 2.5cm H

 Weight
 2.7 kg

Technical Information

Technical Documents

Guidelines for PIG Acid Encapsulating and Neutralizing Absorbents

PIG® Acid Encapsulating / Neutralizing Absorbents

Disclaimers

HAZ-MAT Notice

To ensure effectiveness and your safety, we recommend that you conduct compatibility and absorption testing of your chemicals with PIG® HAZ-MAT products prior to purchase. If you have any questions or need samples to test, please call Technical Services.

Acid Absorbents Notice

Not for use with hydrofluoric acid as it may create a hazardous gas.



One Pork Avenue • Tipton, PA 16684-0304

1-855-493-4647 • Fax: 1-800-621-7447 • newpig.com • hothogs@newpig.com